


NimoCam Projecter

Video preview



2011-11-09

C:\Documents and Settings\wu\桌面

Saving file the path

1600 * 1200 JPG / ASF

00 : 00 : 00

Show date recently

Brightness and contrast ratio adjusting

Signal source select (if have multi source)

Image spin function

Snap short

Image reduction

normal

Image enlarge

Dynamic recording

Resolution optional (more big more)

Image full screen preview (Esc exist)

The diagram illustrates the layout of the NimoCam Projecter software interface. It features a main video preview area at the top, a toolbar with various icons for settings, recording, and playback, and a bottom section with labels for specific functions. The labels are as follows:

- Video preview**: Points to the main video display area.
- C:\Documents and Settings\wu\桌面**: Points to the file path display area.
- Saving file the path**: Points to the file path display area.
- 2011-11-09**: Points to the date display area.
- 1600 * 1200 JPG / ASF**: Points to the resolution and format display area.
- 00 : 00 : 00**: Points to the time display area.
- Show date recently**: Points to the date display area.
- Brightness and contrast ratio adjusting**: Points to the brightness and contrast adjustment icons.
- Signal source select (if have multi source)**: Points to the signal source selection icon.
- Image spin function**: Points to the image spin function icon.
- Snap short**: Points to the snapshot icon.
- Image reduction**: Points to the image reduction icon.
- normal**: Points to the normal view icon.
- Image enlarge**: Points to the image enlarge icon.
- Dynamic recording**: Points to the dynamic recording icon.
- Resolution optional (more big more)**: Points to the resolution adjustment icon.
- Image full screen preview (Esc exist)**: Points to the full screen preview icon.